



Zexa Platinum Rinse Aid Fast Dry - Dishwashers

Rinse aid has one purpose: to allow for faster drying of cups, plates and cutlery and reduce water marks on wash items. Highly concentrated for low dosing into machines.

Description:

Platinum Rinse Aid breaks the surface tension in the water. This enables excess water to sheet away and off glassware.

Together with the heat generated by the washing process, it reduces drying time. Importantly, it reduces water marking on all wares.

Applications:

- Helpful in busy bars and kitchens to make manual drying easier.
- If used with Zexa Glass and Dish or Zexa Dish this product will not build up like normal rinse aid
- Use where hard water is present to reduce scale build up.

Sizes:

- 5lt Containers
- 15lt Containers